

Refill Instructions

Canon BC-20; BC-23

1. Remove plug on top of cartridge with included eyelet screw, as shown.



2. Attach the needle to the syringe and fill with black ink.
3. Insert the syringe through the filling hole and push all the way into the cartridge.
Note: *You may feel a slight pressure because the cartridge contains a sponge.*

4. Slowly inject up to 30 ml of ink then replace the plug on the top of the cartridge.

5. Unused ink may be returned to the bottle.

Rinse the syringe with water and dry for future use, or use with a different color ink.

6. Reinsert the cartridge(s) and run a priming cycle as per printer instructions.
If necessary leave cartridge in printer for up to 24 hours. (Allow ink to flow to the print head).

Note: *Immediately refill any empty cartridges.*