

Refill Instructions

Canon BC-61; BCI-61



1. Peel back label on top of cartridge enough to expose the filling holes, as shown in photo.
2. Use the eyelet screw included and screw it into the lower leveled area under the label until eyelet screw fully pierces cartridge.
3. Attach the needle to the syringe and fill with the appropriate color ink.
4. Inject approximately 10 ml of ink slowly into the sponge until the cartridge is

Note: You may feel a slight pressure because the cartridge contains a sponge.

5. Use transparent tape to seal the hole made in the top label.
6. Unused ink may be returned to the bottle. Rinse the syringe with water and dry between each color refill or store for future use.



7. Reinsert the cartridge and run 1 - 3 cleaning cycles as per printer instructions. If necessary leave cartridge in printer for up to 24 hours which allows ink to flow to the print head.

Note: This time is greatly reduced if the cartridge is refilled before it is completely empty.