

Refill Instructions

Canon BCI -15Bk



Outlet
Hole



1. Carefully peel back the label on the top of the cartridge(s).
2. Using the included eyelet screw enlarge the filling hole(s) on the top of the cartridge. (as shown at right.)



3. Fill the syringe with ink, insert the filling needle no more than half way in to the cartridge and inject approximately 4 ml of ink or until the cartridge is full.
4. Replace the label and reinsert cartridge into printer and print one or two test pages. See general tips on page 2 for location of test page.

Note: Immediately refill any empty cartridges.