

## Refill Instructions

### Canon BX-02

1. Using the screw provided remove the vented plug(s) from the filler hole(s). (Screw it into the small vent hole and pull the plug out). OR enlarge the opening of the vent hole(s), using the eyelet screw, to allow the filling needle to fit in.



2. Attach the needle to the syringe and fill with the proper color ink.
3. Insert the syringe through the appropriate filling hole, (See diagram for filling hole color) and push into the cartridge.

***Note: You may feel a slight pressure because the cartridge contains a sponge. Continue pushing toward the inside until the filling needle reaches the other side of the cartridge.***

4. Slowly inject approximately 20 ml of ink, per chamber, or until ink appears at the filling hole. Unused ink can be returned to the bottle.
5. Rinse the syringe with water and dry for future use, or use with a different color ink.
6. Refit the plug(s) in the filler hole(s) if removed in step one.
7. Reinsert the cartridge and run a priming cycle as per printer instructions.

**Note:** Immediately refill any empty cartridges.