



Refill Instructions

HP C6625DN;

1. The filling holes are located on top of the cartridge and are sealed with small plastic plugs. These must be removed by pushing them into the cartridge using a pointed object (e.g. a ball point pen tip)



2. Attach the needle to the syringe and fill with the correct color ink.
3. Insert the filling needle into the corresponding filler hole of the color to be refilled, (see diagrams) and push all the way down into the center of the cartridge.



Note: You may feel a slight pressure because the cartridge contains a sponge.

4. Slowly inject approximately 10 ml of ink, per chamber, until the ink surfaces at the filling hole. It is not necessary to reseal the filling

holes.

Important: Rinse the syringe with water, and dry between each color refill and store for future use.

Note: Immediately refill any empty cartridges.