

## Refill Instructions

### LEXMARK 18C0781E (No.1)

1. Put the cartridge on some paper towels in an area where you can tolerate a spill.



2. Peel off the top label.
3. Fill the syringe with 7 ml. of color ink.
4. Very S-L-O-W-L-Y inject ink into each chamber until the sponge is full. A little ink might come out of the top when full, so cover up the other two holes while filling one.

5. When finished, replace the top label or leave it off (it will make no difference in the printing).

Replace the cartridge and run 1 - 3 cleaning cycles as per printer instructions.

If necessary leave cartridge in printer for up to 8 hours.

The cartridge will print just like a new one. Even though the cartridge prints good, the ink level gauge will not read full after a refill.



**Note:** After refilling the cartridge change the settings on your printer to best print and run 6-7 test pages to restore the print quality.

**Note:** Immediately refill any cartridge that has become empty.