

Refill Instructions

Canon CL-41;


1. The filler pads of the cartridge are located under the top. Remove the top before refilling by carefully prying it off with pocket knife.



2. Insert the filling needle into the filler pad of the color to be refilled.

4. Slowly inject up to 5 ml. of ink until the sponge is saturated.

Important: When you take off the color cartridge cap will notice that the sponge is white. Do not change the sponge color. Fill the individual colors until the color just begins to show in the white sponge.



5. After refilling the top can be put back on with scotch tape.

6. Replace the cartridge and run 1 - 3 cleaning cycles as per printer instructions.

If necessary leave cartridge in printer for up to 24 hours. (That allows ink to flow to the print head).