## **Refill Instructions**

**Lexmark 18L0032**;

1. Using the eyelet screw included widen the filling hole. (Do not remove the top).



- 2. Fill the syringe with 8 ml of Cartridge & Print Head Cleaner and inject into the cartridge. Reinsert cartridge into printer and print 5 test pages. See general tips for location of test page.
- 3. Fill the syringe with ink, insert the filling needle into the filling hole and push as far down into the cartridge. Inject approximately 12-14 ml of ink slowly or until the reservoir is full. After refilling and running the test pages restore the settings to economy to minimize the ink usage.

Note: Immediately refill any empty cartridges.